

Self Adhesive Panel Instructions

Supplies:

- LOFTwall™ Double Sided Adhesive Infill
- Cover Material (fabric, wallpaper, etc.)
- Sharp Scissors/Rotary or Utility Knife
- Pencil or Pen
- Cutting Matt or surface to cut on
- Table or Workspace area

*Optional Steamer/Iron to press out wrinkles on fabric

Buy fabrics from fabric/craft store or use new/old bed sheets. Fun bold or random prints require less alignment , uniform patterns will require more awareness of alignment. Thin, lightweight fabrics are preferred over thicker/heavy fabrics. Prep fabric by steaming or ironing out deep wrinkles.

1. Lay material print face down on worksurface, paying close attention to orientation of the print.
2. Lay the adhesive panel on top of material and position it to cover both faces of the panel(fold line). Once panel is positioned, mark fabric on the corners and edges with a pen or pencil.Cut fabric/material so it is slightly oversize of the panel. Leave about 1 inch around your panel location marks.
- 3.Carefully peel paper from one side of the Double Sided Adhesive panel.
4. Position the adhesive side down and align to marks created when positioning the panel. Press firmly on the panel when applying to the material. Lift panel with fabric adhered along the fold line. If material wrinkles or has inconsistencies, carefully remove fabric slightly from the nearest edge and re-apply that area.
5. Peel paper from second side of adhesive panel and apply to second side of fabric. Press firmly to secure material to the adhesive panel(repeat step 4). Cut and trim remaining fabric to the edges of panel.

Panel is now ready to slide into the LOFTwall frame.

