



# THIN

## ceiling mounting

### Tools



Power Drill  
(Not Included)




Wire Cutters  
(Not Included)




Crimper  
(Not Included)

### Product Styles



Base




Pitch



Wave


### Warning

It is important to utilize the correct screws for each corresponding ceiling and floor surface. Screws are not provided. Screws should be able to support 40 lbs of weight.




# Thin ceiling coupler assembly


## Parts List




**Step 1** Using a bolt and nut, attach an adjustable clamp to the Thin baffle using the precut holes. Repeat this process one more time to complete step 1.




**Step 2** Before cutting wire, determine the desired length and add 2-3 more inches; this will allow wiggle room for hanging. Cut the wire to the desired length making sure the wire lengths match.




**Step 3** Using the cut wire, slide one end through the top of the clamp. To adjust the wire push down on the top of the clamp and pull the wire to its desired length. Do not cut any wire at this point in the process.



**Step 4** Slide the bottom half of the ceiling coupler onto the wire, making sure the threaded side is facing away from the panel. Crimp the wire coupler to the end of the wire. Repeat



**Step 5** Using a drill attach the upper half of the ceiling coupler to the ceiling using appropriate screws for your ceiling. There is 31.5" between each clamp.



**Step 6** Raise the baffle and all attached parts to the ceiling and screw the bottom half of the ceiling coupler into the top half.

